

1.

5.

7.

## Installation Instructions for Suspended Mount Linear Extrusion

Install as per Electrical Code by certified electrician.

Attached Threaded 2. Stud to Cross Bar and mount to J-Box.

Connect the power 3. wires and attach the Plastic Grommet to the cord.

Slide Threaded Stud 4. through Ceiling Canopy and secure Cable Mount Nut.

> Attach Ceiling Coupler to the ceiling on the nonpower side. (Screw is not Included)

Slide Aircraft Cables 6. to each end of the Cable Gripper mounted to the luminaire.

> Adjust height, level the luminaire and then cut the access cable



